



*NOTE: A BUFFER SHEET IS REQUIRED UNDER A STONE OR TILE COPING.

PARAPET WITH METAL COPING Terminations Details			2250 SOUTH TENTH STREET SAN JOSE, CA 95112 800-669-7010 • 408-297-3500	
	<small>DRAWN</small> SR/BR	<small>DATE</small> 1998	<small>REV.</small>	T-98